

RYOBI

Ryobi telemeter



Descriptif produit



Ref : RYOBITELEMETRE

EAN : 4892210132611

Compatible mobiles

ALCATEL

A3 / A5 LED / IDOL 3 (4.7) / IDOL 4 / ONE TOUCH IDOL 2S / POP 3 5.0 / POP 4 / 1X (5059) / 3 (5052) / 3C (5026) / 3V (5099) / 5V (5060) / A3 XL / U5

APPLE

IPAD AIR 2 9.7 (2014) / IPAD MINI 3 7.9 (2014) / IPAD PRO / IPAD PRO 9.7 / IPHONE 4S / IPHONE 5 / IPHONE 5C / IPHONE 5S / IPHONE 6 / IPHONE 6 PLUS / IPHONE 6S / IPHONE 6S PLUS / IPHONE 7 / IPHONE 7 PLUS / IPHONE 7 PLUS RED / IPHONE 7 RED / IPHONE SE / IPAD 6 9.7 (2018) / IPAD 7 10.2 (2019) / IPAD MINI 4 7.9 (2015) / IPAD PRO 10.5 / IPHONE 11 / IPHONE 11 PRO / IPHONE 11 PRO MAX / IPHONE 12 / IPHONE 12 MINI / IPHONE 12 PRO / IPHONE 12 PRO MAX / IPHONE 8 / IPHONE 8 PLUS / IPHONE SE (2020) / IPHONE X / IPHONE XR / IPHONE XS / IPHONE XS MAX

CROSSCALL

TREKKER X3 / TREKKER M 1 / ACTION X3

ECHO

BUZZ / JAVA / LOLLY / PUSH / SMART4G / STAR / SURF / VOLT

HTC

10 / DESIRE 530 / DESIRE 650 / DESIRE 825 / ONE M8 / ONE M9

HUAWEI

ASCEND P7 / MATE S / P10 / P10 Lite / P10 PLUS / P8 LITE 2016 / Y3 / Y5 II / P40 LITE E / Y6 2017

LG

G4 / G4 C / K10 / K4 / K9 (Candy) / Q6

LOGICOM

E350 / E500

MOTOROLA

MOTO E4 PLUS

NOKIA

3.1

SAMSUNG

GALAXY A3 A300 / GALAXY A3 A310 2016 / GALAXY A5 A500 / GALAXY A5 A510 2016 / GALAXY A7 A700 / GALAXY ACE 3 S7270 / GALAXY ACE 4 4G G357 / GALAXY ALPHA G850 / GALAXY CAMERA GC100 / GALAXY CORE 4G G386 / GALAXY CORE I8260 / GALAXY CORE PLUS G3500 / GALAXY CORE PRIME G360 / GALAXY EXPRESS I8730 / GALAXY GRAND 2 G7100 / GALAXY GRAND PRIME G530 / GALAXY J1 J100 / GALAXY J1 J120 2016 / GALAXY J3 J320 2016 / GALAXY J5 J500 / GALAXY J5 J510 2016 / GALAXY J7 J710 2016 / GALAXY MEGA 5.8 I9150 / GALAXY MEGA I9200 / GALAXY NOTE 2 N7100 / GALAXY NOTE 3 LITE N7505 / GALAXY NOTE 3 N9000 / GALAXY NOTE 4 N910 / GALAXY S 3 4G I9305 / GALAXY S 3 I9300 / GALAXY S 3 MINI I8190 / GALAXY S 4 I9500 / GALAXY S 4 MINI I9190 / GALAXY S 4 ZOOM / GALAXY S 5 G900 / GALAXY S 5 MINI G800 / GALAXY S 6 EDGE G925 / GALAXY S 6 EDGE PLUS G928 / GALAXY S 6 G920 / GALAXY S 7 EDGE G935 / GALAXY S 7 G930 / GALAXY TAB 2 10.1 P5110 / GALAXY TAB 4 10.1 T530 / GALAXY TAB 4 7.0 T230 / GALAXY TAB S 10.5 T800 / GALAXY TREND 2 LITE G318 / GALAXY TREND LITE S7390 / GALAXY XCOVER 3 G388 / GALAXY XCOVER 4 / GALAXY TAB A 10.1 T580 (2016) / GALAXY TAB A 7.0 T280 (2016)

SFR

STARTRAIL 6 / STARTRAIL 8

SONY

XPERIA E1 / XPERIA E5 / XPERIA M4 AQUA / XPERIA T3 / XPERIA X / XPERIA XA / XPERIA Z / XPERIA Z2 / XPERIA Z3 / XPERIA Z3 COMPACT / XPERIA Z5 / XPERIA Z5 COMPACT

WIKO

BIRDY / CINK FIVE / CINK PEAX / CINK PEAX 2 / DARKFULL / DARKMOON / DARKKNIGHT / DARKSIDE / FEVER / FREDDY / HIGHWAY / JERRY / LENNY / LENNY 2 / LENNY 3 / OZZY / PULP 4G / PULP FAB / RAINBOW 4G / RAINBOW JAM 4G / RAINBOW LITE 4G / ROBBY / STAIRWAY / SUNNY / SUNSET 2 / TOMMY / U FEEL LITE / HARRY / JERRY 2 / LENNY 4 / SUNNY 2 / SUNNY 2 PLUS / SUNNY 3 / U PULSE / U PULSE LITE / WIM / WIM LITE