

**USB / micro USB connectors / Lightning Silver Colorblock**



**Descriptif produit**



**Ref : CB2MCABLESLV**  
**EAN : 3571211333425**



**Compatible mobiles**

**ALCATEL**

1 (5033) / 1B 2020 / 1S (2020) / 1X (5059) / 1X 2019 (5008) / 3 (5052) / 3C (5026) / 3L (5034) / 3L 2020 / 3V (5099) / 3X (5058) / 5 (5086) / 5V (5060) / 1S (2021) / 1S (5024) / A3 / A3 XL / A5 LED / IDOL 3 (4.7) / IDOL 4 / ONE TOUCH IDOL 2S / POP 3 5.0 / POP 4 / U5

**APPLE**

AIRPODS / AIRPODS PRO / IPAD 4 9.7 (2012) / IPAD 6 9.7 (2018) / IPAD AIR 1 9.7 (2013) / IPAD MINI 1 7.9 (2012) / IPAD MINI 3 7.9 (2014) / IPAD PRO 10.5 / IPHONE 12 / IPHONE 12 MINI / IPHONE 12 PRO / IPHONE 12 PRO MAX / IPHONE 5S / IPHONE SE (2020) / IPHONE XR / IPHONE XS / IPHONE XS MAX / AIRPODS 2 / AIRPODS 3 / AIRPODS PRO 2 / IPAD 10 10.9 (2022) / IPAD 2 9.7 (2011) / IPAD 3 9.7 (2012) / IPAD 5 9.7 (2017) / IPAD 7 10.2 (2019) / IPAD AIR 2 9.7 (2014) / IPAD MINI 4 7.9 (2015) / IPAD PRO / IPAD PRO 11 2020 / IPAD PRO 9.7 / IPHONE 11 / IPHONE 11 PRO / IPHONE 11 PRO MAX / IPHONE 13 / IPHONE 13 MINI / IPHONE 13 PRO / IPHONE 13 PRO MAX / IPHONE 14 / IPHONE 14 PLUS / IPHONE 14 PRO / IPHONE 14 PRO MAX / IPHONE 5 / IPHONE 5C / IPHONE 6 / IPHONE 6 PLUS / IPHONE 6S / IPHONE 6S PLUS / IPHONE 7 / IPHONE 7 PLUS / IPHONE 7 PLUS RED / IPHONE 7 RED / IPHONE 8 / IPHONE 8 PLUS / IPHONE SE / IPHONE X

**BLACKBERRY**

CURVE 9320 / Q10 / Q5

**CROSSCALL**

ACTION X3 / TREKKER X3 / TREKKER X4 / TREKKER M 1

**DORO**

6530 / 8035 / 8040 / 6620 / 6621 / 6880 / 7060

**ECHO**

BUZZ / DUNE / FEELING / FLOW / FUSION / HALO / HORIZON / HORIZON M / JAVA / LOLLY / LOOK / NOTE / PUSH / SMART4G / STAR / STELLAR / SURF / VOLT / WIZ

**GOOGLE**

PIXEL 4 / PIXEL 4 XL

**HONOR**

HONOR 10 LITE / HONOR 20 / HONOR 6A / HONOR 6C / HONOR 6C PRO / HONOR 7A / HONOR 7C / HONOR 7S / HONOR 7X / HONOR 8A / HONOR 8X / HONOR 9 LITE / HONOR 9A / HONOR 9X LITE / HONOR PLAY / HONOR 20 LITE / HONOR 5C / HONOR 5X / HONOR 6X / HONOR 8S / HONOR 9X / HONOR X7 / HONOR X8

**HTC**

7 PRO / DESIRE 530 / DESIRE 650 / DESIRE 825 / ONE A9 / ONE M8 / ONE M9

**HUAWEI**

MATE 10 LITE / MEDIAPAD T3 10 / P SMART / P SMART 2019 / P20 LITE / P40 LITE E / Y5 2018 / Y5P / Y6 PRO 2017 / Y6P / Y6S (2019) / Y7 2018 / ASCEND P7 / MATE S / P10 Lite / P20 LITE 2019 / P8 / P8 LITE 2016 / P8 LITE 2017 / P9 LITE / Y3 / Y5 2019 / Y5 II / Y6 2017 / Y6 2019 / Y7 2019

**LG**

G4 C / K11 / K22 / K51S / K9 (Candy) / G4 / K10 / K4 / K40 / K40S / K50S / Q6 / Q60

**LOGICOM**

E350 / E500 / FIVE / FLOW / WAVE

**MOTOROLA**

MOTO E4 PLUS

**NOKIA**

1 2018 / 2 / 3.1 / 3310 2017 / 5.1 / 3 / 5 / 6 / XL

**OPPO**

A12 / A15 / A3 / A31 / FIND X / R15 PRO / RX17 NEO / A5 (2020) / A9 (2020) / AX7

**ORANGE**

RISE 52 / NEVA PLAY / NEVA ZEN

**REALME**

C11 / C11 2021 / C21 / C21Y / C30 / C31 / C33

**SAMSUNG**

GALAXY A02s A025/026 / GALAXY A6 A600 2018 / GALAXY A6+ A605 2018 / GALAXY A7 A750 2018 / GALAXY A9 A920 2018 / GALAXY ACE S5830 / GALAXY J2 PRO J250 2018 / GALAXY J4+ J415 / GALAXY J5 J530 2017 / GALAXY J6 J600 / GALAXY J6+ J610 / GALAXY J7 J730 2017 / GALAXY S 5 G900 / GALAXY TAB A 10.1 T580 (2016) / GALAXY TAB A 10.5 2018 / GALAXY TAB A 7.0 T280 (2016) / GALAXY A03 A035 / GALAXY A05s 057 / GALAXY A10 A105 / GALAXY A3 A300 / GALAXY A3 A310 2016 / GALAXY A5 A500 / GALAXY A5 A510 2016 / GALAXY A7 A700 / GALAXY ACE 3 S7270 / GALAXY ACE 4 4G G357 / GALAXY ALPHA G850 / GALAXY CAMERA GC100 / GALAXY CORE 4G G386 / GALAXY CORE I8260 / GALAXY CORE PLUS G3500 / GALAXY CORE PRIME G360 / GALAXY EXPRESS I8730 / GALAXY GRAND 2 G7100 / GALAXY GRAND PRIME G530 / GALAXY J1 J100 / GALAXY J1 J120 2016 / GALAXY J3 J320 2016 / GALAXY J3 J330 2017 / GALAXY J5 J500 / GALAXY J5 J510 2016 / GALAXY J7 J710 2016 / GALAXY MEGA 5.8 I9150 / GALAXY MEGA I9200 / GALAXY NEXUS I9250 / GALAXY NOTE 2 N7100 / GALAXY NOTE 3 LITE N7505 / GALAXY NOTE 3 N9000 / GALAXY NOTE 4 N910 / GALAXY S 3 4G I9305 / GALAXY S 3 I9300 / GALAXY S 3 MINI I8190 / GALAXY S 4 I9500 / GALAXY S 4 MINI I9190 / GALAXY S 4 ZOOM / GALAXY S 5 MINI G800 / GALAXY S 6 EDGE G925 / GALAXY S 6 EDGE PLUS G928 / GALAXY S 6 G920 / GALAXY S 7 EDGE G935 / GALAXY S 7 G930 / GALAXY TAB 10.1 P7100 / GALAXY TAB 4 10.1 T530 / GALAXY TAB 4 7.0 T230 / GALAXY TAB A 8 T295 (2019) / GALAXY TAB A 8.0 (2020) / GALAXY TAB A8 8 (2017) / GALAXY TAB S 10.5 T800 / GALAXY TAB S5E / GALAXY TREND 2 LITE G318 / GALAXY TREND LITE S7390 / GALAXY XCOVER 3 G388 / GALAXY XCOVER 4 / GALAXY XCOVER 7

**SFR**

STARSHINE 5 / STARTRAIL 6 / STARTRAIL 8

**SONY**

XPERIA XA2 PLUS / XPERIA E1 / XPERIA E5 / XPERIA M4 AQUA / XPERIA T3 / XPERIA X / XPERIA XA / XPERIA Z / XPERIA Z2 / XPERIA Z3 / XPERIA Z3 COMPACT / XPERIA Z5 / XPERIA Z5 COMPACT

**VIVO**

Y11s / Y20 / Y20s / Y70 / Y01 5G / Y11

**WIKO**

HARRY / HARRY 2 / JERRY 3 / LENNY 5 / RAINBOW JAM 4G / SUNNY 2 / SUNNY 2 PLUS / SUNNY 3 / TOMMY 2 / TOMMY 2 PLUS / TOMMY 3 / VIEW / VIEW 4 / VIEW 4 LITE / VIEW 5 / VIEW GO / VIEW LITE / VIEW MAX / VIEW PRIME / VIEW XL / VIEW2 / Y61 / Y81 / BIRDY / CINK FIVE / CINK PEAX / CINK PEAX 2 / DARKFULL / DARKMOON / DARKNIGHT / DARKSIDE / FEVER / FREDDY / HIGHWAY / JERRY / JERRY 2 / LENNY / LENNY 2 / LENNY 3 / LENNY 4 / OZZY / PULP 4G / PULP FAB / RAINBOW 4G / RAINBOW LITE 4G / ROBBY / STAIRWAY / SUNNY / SUNSET 2 / TOMMY / U FEEL LITE / U PULSE / U PULSE LITE / VIEW 3 / VIEW 3 LITE / VIEW 5 PLUS / WIM / WIM LITE / Y50 / Y51 / Y52 / Y60 / Y62 / Y62 Plus / Y80

**XIAOMI**

MI A2 / POCOPHONE F1 / REDMI 5 / REDMI 6 / REDMI 6A / REDMI 9A / REDMI 9C / REDMI NOTE 5 / REDMI S2 / REDMI 10A / REDMI 12C / REDMI 7 / REDMI 7A / REDMI 9C NFC / Redmi A1 / REDMI A2 / REDMI GO