



Descriptif produit



Ref : NRDNMATE2SILWB

EAN : 6970754370657

Compatible mobiles

ALCATEL

1X (5059) / 3 (5052) / 3C (5026) / 3V (5099) / 3X (5058) / 5 (5086) / 5V (5060) / A3 / A3 XL / A5 LED / IDOL 3 (4.7) / IDOL 4 / ONE TOUCH IDOL 2S / POP 3 5.0 / POP 4 / U5 / 1B 2020 / 1S (2020) / 1S (5024) / 3X 2019 (5048)

APPLE

IPAD 6 9.7 (2018) / IPAD MINI 1 7.9 (2012) / IPAD MINI 3 7.9 (2014) / IPAD MINI 4 7.9 (2015) / IPAD PRO / IPAD PRO 10.5 / IPAD PRO 9.7 / IPHONE 5 / IPHONE 6S / IPHONE 6S PLUS / IPHONE 7 / IPHONE 7 RED / IPHONE 8 / IPHONE 8 PLUS / IPHONE SE / IPHONE SE (2020) / IPHONE X / IPHONE XR / IPHONE XS / IPHONE XS MAX / IPAD 7 10.2 (2019) / IPHONE 11 / IPHONE 11 PRO / IPHONE 11 PRO MAX / IPHONE 12 / IPHONE 12 MINI / IPHONE 12 PRO / IPHONE 12 PRO MAX

BLACKBERRY

KEY2

CROSSCALL

ACTION X3 / CORE X3 / TREKKER X3 / TREKKER M 1 / CORE M4 / CORE X4

DORO

8035 / 8040

ECHO

BUZZ / DUNE / FEELING / FLOW / FUSION / HALO / HORIZON / HORIZON LITE / HORIZON LITE PLUS / HORIZON M / JAVA / LOLLY / LOOK / NOTE / PUSH / SMART4G / STAR / STELLAR / SURF / VOLT / WIZ

GOOGLE

PIXEL 3 / PIXEL 3 XL / PIXEL 4 XL / PIXEL 3a / PIXEL 4

HONOR

HONOR 10 / HONOR 5C / HONOR 5X / HONOR 6A / HONOR 6C / HONOR 6X / HONOR 7A / HONOR 7C / HONOR 7S / HONOR 7X / HONOR 8 / HONOR 8A / HONOR 8X / HONOR 9 / HONOR 9 LITE / HONOR PLAY / HONOR 20 / HONOR 20 LITE / HONOR 8S / HONOR 9X

HTC

10 / DESIRE 530 / DESIRE 650 / DESIRE 825 / ONE A9 / ONE M8 / ONE M9 / U PLAY / U11

HUAWEI

ASCEND P7 / MATE 10 LITE / MATE 10 PRO / MATE 20 / MATE 20 LITE / MATE 20 PRO / MATE S / MEDIAPAD T3 10 / P SMART / P SMART 2020 / P10 / P10 Lite / P10 PLUS / P20 / P20 LITE / P20 PRO / P30 / P30 PRO / P40 / P40 LITE / P40 PRO / P8 / P8 LITE 2016 / P8 LITE 2017 / P9 / P9 LITE / Y3 / Y5 2018 / Y5 II / Y6 2017 / Y6 2019 / Y6 PRO 2017 / Y6S (2019) / Y7 2018 / MATE 30 PRO / NOVA 5T / P SMART PRO 2019 / P SMART S / P SMART Z / P20 LITE 2019 / P30 LITE / P40 LITE 5G / P40 LITE E / Y5 2019 / Y5P / Y6P

LG

G4 / G4 C / K10 / K11 / K4 / K40S / K50S / K9 (Candy) / Q6 / K40 / Q60

MOTOROLA

MOTO E4 PLUS

NOKIA

1 2018 / 2 / 3 / 3.1 / 5 / 5.1 PLUS / 6 / 7 PLUS / 7.1 / XL / 9 PUREVIEW

ONEPLUS

6T / 7 / 7 PRO

OPPO

A3 / FIND X / FIND X2 LITE / FIND X2 NEO / FIND X2 PRO / R15 PRO / RX17 NEO / A5 (2020) / A72 / A9 (2020) / RENO 10X ZOOM / RENO 2 / RENO 2F / RENO 2Z / RENO Z

ORANGE

RISE 52 / NEVA JET / NEVA PLAY / NEVA ZEN

SAMSUNG

GALAXY A21S A217 / GALAXY A3 A300 / GALAXY A3 A310 2016 / GALAXY A3 A320 2017 / GALAXY A40 A405 / GALAXY A41 A415 / GALAXY A5 A500 / GALAXY A5 A510 2016 / GALAXY A5 A520 2017 / GALAXY A50 A505 / GALAXY A6 A600 2018 / GALAXY A6+ A605 2018 / GALAXY A7 A700 / GALAXY A7 A750 2018 / GALAXY A70 A705 / GALAXY A71 A715 / GALAXY A8 A530 2018 / GALAXY ACE 4 4G G357 / GALAXY ALPHA G850 / GALAXY CORE PRIME G360 / GALAXY GRAND 2 G7100 / GALAXY GRAND PRIME G530 / GALAXY J1 J100 / GALAXY J1 J120 2016 / GALAXY J2 PRO J250 2018 / GALAXY J3 J320 2016 / GALAXY J3 J330 2017 / GALAXY J5 J500 / GALAXY J5 J510 2016 / GALAXY J5 J530 2017 / GALAXY J6 J600 / GALAXY J6+ J610 / GALAXY J7 J710 2016 / GALAXY J7 J730 2017 / GALAXY NOTE 10 LITE / GALAXY NOTE 3 LITE N7505 / GALAXY NOTE 3 N9000 / GALAXY NOTE 4 N910 / GALAXY NOTE 8 N950 / GALAXY NOTE 9 N960 / GALAXY S 10 + G975 / GALAXY S 20 + G985 / GALAXY S 20 G980 / GALAXY S 20 ULTRA G988 / GALAXY S 5 G900 / GALAXY S 5 MINI G800 / GALAXY S 6 EDGE G925 / GALAXY S 6 EDGE PLUS G928 / GALAXY S 6 G920 / GALAXY S 7 EDGE G935 / GALAXY S 7 G930 / GALAXY S 8 G950 / GALAXY S 9 + G965 / GALAXY S 9 G960 / GALAXY TAB 4 10.1 T530 / GALAXY TAB 4 7.0 T230 / GALAXY TAB A 10.1 T580 (2016) / GALAXY TAB A 7.0 T280 (2016) / GALAXY TAB S 10.5 T800 / GALAXY TREND 2 LITE G318 / GALAXY XCOVER 3 G388 / GALAXY XCOVER 4 / GALAXY XCOVER PRO / GALAXY A10 A105 / GALAXY A20e A202 / GALAXY A31 A315 / GALAXY A51 5G A516 / GALAXY A51 A515 / GALAXY A80 A805 / GALAXY FOLD / GALAXY NOTE 10 + N975 / GALAXY NOTE 10 N970 / GALAXY NOTE 20 5G / GALAXY NOTE 20 ULTRA / GALAXY S 10 5G G977 / GALAXY S 20 FE G780 / GALAXY TAB A 10.5 2018 / GALAXY TAB S5E

SFR

STARSHINE 5

SONY

XPERIA 10 / XPERIA 10 PLUS / XPERIA E1 / XPERIA E5 / XPERIA L1 / XPERIA L3 / XPERIA M4 AQUA / XPERIA T3 / XPERIA X / XPERIA XA / XPERIA XA1 ULTRA / XPERIA XA2 / XPERIA XA2 PLUS / XPERIA XA2 ULTRA / XPERIA XZ / XPERIA XZ PREMIUM / XPERIA XZ1 / XPERIA XZ1 COMPACT / XPERIA XZ2 / XPERIA Z2 / XPERIA Z3 / XPERIA Z3 COMPACT / XPERIA Z5 / XPERIA Z5 COMPACT / XPERIA 1 / XPERIA 5

WIKO

BIRDY / FEVER / FREDDY / HARRY / JERRY / JERRY 2 / JERRY 3 / LENNY / LENNY 2 / LENNY 3 / LENNY 4 / LENNY 5 / PULP 4G / PULP FAB / RAINBOW 4G / RAINBOW JAM 4G / RAINBOW LITE 4G / ROBBY / SUNNY / SUNNY 2 / SUNNY 2 PLUS / SUNNY 3 / SUNSET 2 / TOMMY / TOMMY 2 / TOMMY 2 PLUS / U FEEL LITE / U PULSE / U PULSE LITE / VIEW / VIEW GO / VIEW LITE / VIEW MAX / VIEW PRIME / VIEW XL / VIEW2 / WIM / WIM LITE

XIAOMI

MI 8 LITE / MI A2 / MI MIX 2 / MI MIX 2S / POCOPHONE F1 / REDMI 6 / REDMI 6A / REDMI NOTE 10 / REDMI NOTE 5 / REDMI NOTE 8 PRO / REDMI NOTE 8T / MI 9 / MI 9 LITE / MI 9 SE / MI 9T / MI 9T PRO / MI A3 / REDMI 7 / REDMI 7A / REDMI 8 / REDMI 8A / REDMI 9 / REDMI 9C / REDMI GO / REDMI NOTE 10 PRO / REDMI NOTE 7 / REDMI NOTE 8 / REDMI NOTE 9 PRO / REDMI NOTE 9S