

# 12000mAh Powerbank FastCharge 15W USB A+C Safari Red Fresh'n Rebel



## Descriptif produit



**This amazing powerbank is here to save the day. Never leave home without an extra source of power for your wireless devices, such as your smartphone, tablet, headphones, portable speaker or gaming console. The 12000 mAh Powerbank charges your phone 4 times and your tablet 2 times.**

### Pocket size

All Powerbanks are nicely shaped, ultra-light and designed to fit in any pocket or bag. They are small in size, yet very powerful and the perfect companion for your travels. With the new "high density" compression technology, we've been able to reduce the size and weight of our Powerbanks by over 30%, while maintaining the same capacity.

### Connections

Charge multiple devices. With the USB-C port, you can charge the Powerbank itself, but also devices like your phone, speaker or headphones. With the USB port on the Powerbank, or even the 2 USB ports on the 18000 mAh Powerbank, you can charge 2 or 3 devices at the same time.

### Power Indicator

Never run out of power. All Powerbanks are equipped with a power indicator, allowing you to check the battery level at any time. Press the button to immediately see how much battery power is left.

### Safety Feature

All Fresh 'n Rebel Powerbanks are equipped with 6 safety features to ensure the safety of all your devices. The 6 safety features protect your devices from power surges, overcurrents, overheating, overcharging, overdischarge and short circuits. These pocket chargers can also be safely transported on airplanes as they are UN38.3 approved by the airlines.

Overvoltage protection

Overcurrent protection

Protection against overheating

Protection against overloads

Protection against excessive discharge

Protection against short circuits

### Quality materials

Powerbanks are made of lightweight, flexible materials with soft curves. On the side, you'll find a vegan leather label with our embossed logo, and on the top of the Powerbank, soft LED status indicators. Always charge your devices in style.

### Charging

Use Powerbanks to quickly charge your devices when you're on the go or too far from a wall outlet. The Powerbank itself also charges in no time and is ready for use before you know it. See the chart below for full details on charging times.

**Color : Safari Red**

**Material : Plastic**

**Ref : FB2PB12000SR**

**EAN : 8720249802488**

**Pack contents : 1 FastCharge Powerbank + USB A to USB C cable**



# Informations complémentaires

Dimensions: 126 x 64 x 21 mm

Weight : 260 g

Charging time : 7H

Battery capacity: 12 000 mAh

USB output: 5 V/3.1 A max.

USB-C input: 5 V/2.1 A max.

USB-C output: 5 V/2.1 A max.

Safety features:

Overvoltage protection

Overcurrent protection

Overheat protection

Overload protection

Protection against excessive discharge

Protection against short circuits

Airline approved: allows safe flight (UN38.3)

Color: Dusky blue

## Compatible mobiles

### ALCATEL

20 SE / 20R 5G / 3X 2019 (5048)

### APPLE

IPAD AIR 4 10.9 2020 / IPAD AIR 5 10.9 2022 / IPAD PRO 11 (2018) / IPAD PRO 12.9 (2018) / IPHONE 15 / IPHONE 15 PLUS / IPHONE 15 PRO / IPHONE 15 PRO MAX

### BLACKBERRY

KEY2

### CROSSCALL

ACTION X3 / ACTION X5 / CORE M4 / CORE M5 / CORE X3 / CORE X4 / CORE Z5 / STELLAR X5 / TREKKER X3 / TREKKER X4

### DORO

8100 / 8200 / 8210 / 8220

### ECHO

HORIZON LITE / HORIZON LITE PLUS

### GOOGLE

PIXEL 3 / PIXEL 3 XL / PIXEL 3a / PIXEL 4 / PIXEL 4 XL / PIXEL 4A / PIXEL 4A 5G / PIXEL 5 / PIXEL 6 / PIXEL 6A / PIXEL 6PRO / PIXEL 7 / PIXEL 7A / PIXEL 7PRO / PIXEL 8A / PIXEL 8PRO

### HONOR

HONOR 10 / HONOR 10X LITE / HONOR 20 / HONOR 20 PRO / HONOR 200 / HONOR 200 LITE / HONOR 200 PRO / HONOR 50 5G / HONOR 50 LITE / HONOR 70 / HONOR 70 LITE / HONOR 8 / HONOR 8A / HONOR 9 / HONOR 90 / HONOR 90 LITE / HONOR 9X / HONOR MAGIC 3 PRO 5G / HONOR MAGIC 4 LITE 5G / HONOR MAGIC 5 LITE 5G / HONOR MAGIC 5 PRO / HONOR MAGIC 6 LITE / HONOR MAGIC V2 / HONOR VIEW 20 / HONOR X6 / HONOR X7a / HONOR X8 / HONOR X8 5G / HONOR X8a / HONORMAGV2

### HTC

10 / U11

### HUAWEI

MATE 10 PRO / MATE 20 / MATE 20 LITE / MATE 20 PRO / MATE 30 PRO / MATE 40 PRO / NOVA 5T / P SMART 2020 / P SMART 2021 / P SMART PRO 2019 / P SMART S / P SMART Z / P10 / P10 PLUS / P20 / P20 LITE / P20 LITE 2019 / P20 PRO / P30 / P30 LITE / P30 PRO / P40 / P40 LITE / P40 LITE 5G / P40 LITE 5G / P40 PRO P9

### LG

LG K51S

### MOTOROLA

MOTO E13 4G / MOTO E14 / MOTO E20 / MOTO E20 LITE / MOTO E22i / MOTO EDGE (2022) / MOTO EDGE 30 NEO / MOTO EDGE 40 / MOTO EDGE 40 NEO / MOTO G04 / MOTO G04s / MOTO G13 / MOTO G14 / MOTO G22 / MOTO G23 / MOTO G24 POWER / MOTO G30 / MOTO G31 / MOTO G32 / MOTO G34 5G / MOTO G50 5G / MOTO G52 / MOTO G53 5G / MOTO G54 5G / MOTO G62 5G / MOTO G72 / MOTO G73 / MOTO G84 / THINKPHONE

### NOKIA

5.1 PLUS / 6 2018 / 6.1 / 7 PLUS / 7.1 / 9 PUREVIEW

### ONEPLUS

6T / 7 / 7 PRO

### OPPO

A16 / A16 S / A17 / A53S / A54 4G / A54 5G / A54 S / A57 / A57S / A72 / A73 4G / A73 5G / A74 / A74 5G / A76 / A77 / A78 5G / A94 5G / A96 / A97 5G / FIND N2 FLIP / FIND X / FIND X2 LITE / FIND X2 NEO / FIND X2 PRO / FIND X3 LITE / FIND X3 NEO / FIND X3 PRO / FIND X5 / FIND X5 LITE / FIND X5 PRO / RENO / RENO 10X ZOOM / RENO 2 / RENO 2F / RENO 2Z / RENO 4 / RENO 4 PRO 5G / RENO 4Z 5G / RENO 5 LITE / RENO 6 / RENO 6 PRO / RENO 8 / RENO 8 LITE / RENO 8 PRO / RENO Z

### ORANGE

NEVA JET

**SAMSUNG**

GALAXY A03S / GALAXY A04S / GALAXY A05s 057 / GALAXY A12 A125 / GALAXY A13 4G A135 / GALAXY A13 5G A136 / GALAXY A14 4G A145 / GALAXY A14 5G A146 / GALAXY A15 4G 156 / GALAXY A15 5G 156 / GALAXY A20 / GALAXY A20e A202 / GALAXY A21S A217 / GALAXY A22 4G / GALAXY A22 5G / GALAXY A23 5G / GALAXY A25 256 / GALAXY A3 A320 2017 / GALAXY A31 A315 / GALAXY A32 4G / GALAXY A32 5G / GALAXY A33 5G A336 / GALAXY A34 5G A346 / GALAXY A35 5G 356 / GALAXY A40 A405 / GALAXY A41 A415 / GALAXY A42 5G / GALAXY A5 A520 2017 / GALAXY A50 A505 / GALAXY A51 5G A516 / GALAXY A51 A515 / GALAXY A52 4G / GALAXY A52s 5G / GALAXY A53 5G A536 / GALAXY A54 5G A546 / GALAXY A55 5G 556 / GALAXY A70 A705 / GALAXY A71 A715 / GALAXY A72 4G / GALAXY A8 A530 2018 / GALAXY A80 A805 / GALAXY A9 A920 2018 / GALAXY BUDS LIVE / GALAXY FOLD / GALAXY M52 5G M526 / GALAXY NOTE 10 + N975 / GALAXY NOTE 10 LITE / GALAXY NOTE 10 N970 / GALAXY NOTE 20 5G / GALAXY NOTE 20 ULTRA / GALAXY NOTE 8 N950 / GALAXY NOTE 9 N960 / GALAXY S 10 G975 / GALAXY S 10 5G G977 / GALAXY S 10 e G970 / GALAXY S 10 G973 / GALAXY S 10 LITE G770 / GALAXY S 20 + G985 / GALAXY S 20 FE G780 / GALAXY S 20 G980 / GALAXY S 20 ULTRA G988 / GALAXY S 21 5G 991 / GALAXY S 21 FE 990 / GALAXY S 21 ULTRA 5G 998 / GALAXY S 21+ 5G 996 / GALAXY S 22 5G 901 / GALAXY S 22 ULTRA 5G 908 / GALAXY S 22+ 5G 906 / GALAXY S 23 5G 911 / GALAXY S 23 FE 711 / GALAXY S 23 ULTRA 5G 918 / GALAXY S 23+ 5G 916 / GALAXY S 24 921 / GALAXY S 24 ULTRA 928 / GALAXY S 24+ 926 / GALAXY S 8 + G955 / GALAXY S 8 G950 / GALAXY S 9 + G965 / GALAXY S 9 G960 / GALAXY TAB A 10.1 (2019) / GALAXY TAB A 10.5 2018 / GALAXY TAB A7 10.4 (2020) T505 / GALAXY TAB A7 Lite 8.7 T220 / GALAXY TAB A8 10.5 X200-205 / GALAXY TAB A9 / GALAXY TAB A9+ / GALAXY TAB ACTIVE 2 / GALAXY TAB ACTIVE 4 PRO 5G / GALAXY TAB ACTIVE 5 / GALAXY TAB ACTIVE 5 EE / GALAXY TAB ACTIVE PRO / GALAXY TAB ACTIVE2 / GALAXY TAB ACTIVE3 / GALAXY TAB S5E / GALAXY TAB S6 LITE 10.4 / GALAXY TAB S7 10 / GALAXY TAB S7 FE 12.4 T730 / GALAXY TAB S7+ 12.4 T970 / GALAXY TAB S9 / GALAXY TAB S9 FE / GALAXY TAB S9 ULTRA / GALAXY TAB S9+ / GALAXY XCOVER 4S / GALAXY XCOVER 5 G525F / GALAXY XCOVER 6 PRO / GALAXY XCOVER 7 / GALAXY XCOVER PRO / GALAXY Z FLIP 3 711 / GALAXY Z FLIP 4 721 / GALAXY Z FLIP 6 741 / GALAXY Z FLIP 700 / GALAXY Z FOLD 2 5G 916 / GALAXY Z FOLD 3 926 / GALAXY Z FOLD 4 936 / GALAXY Z FOLD 5 946 / GALAXY Z FOLD 6 956

**SONY**

SWITCH OLED / XPERIA 1 / XPERIA 10 / XPERIA 10 II / XPERIA 10 PLUS / XPERIA 5 / XPERIA 5 II / XPERIA L1 / XPERIA L3 / XPERIA XA1 ULTRA / XPERIA XA2 / XPERIA XA2 PLUS / XPERIA XA2 ULTRA / XPERIA XZ / XPERIA XZ PREMIUM / XPERIA XZ1 / XPERIA XZ1 COMPACT / XPERIA XZ2 / XPERIA XZ3

**VIVO**

V21 / V21 5G / V23 5G / X 51 / X60 PRO / Y16 4G / Y21 / Y21s / Y22s 4G / Y33s / Y35 4G / Y52 5G / Y55 5G / Y70 / Y72 5G / Y76 5G

**WIKO**

POWER U30 / Y82

**XIAOMI**

11T / 11T PRO / 12 / 12 Lite / 12 PRO / 12T / 12T PRO / MI 10 5G / MI 10 LITE 5G / MI 10 PRO 5G / MI 10T 5G / MI 10T LITE 5G / MI 10T PRO 5G / MI 11 5G / Mi 11 Lite 5G / MI 11 LITE 5G NE / MI 11 PRO 5G / MI 11i / MI 8 LITE / MI 9 / MI 9 LITE / MI 9 SE / MI 9T / MI 9T PRO / MI A1 / MI A2 / MI A3 / MI MIX 2 / MI MIX 2S / MI MIX 3 / MI NOTE 10 LITE / MI NOTE 9 / POCOPHONE F1 / REDMI 10 / REDMI 10 5G / REDMI 10C / REDMI 12 4G / REDMI 12 5G / REDMI 13 / REDMI 13C 4G/5G / REDMI 8 / REDMI 8A / REDMI 9 / REDMI 9T / REDMI A3 / REDMI NOTE 10 / REDMI NOTE 10 5G / REDMI NOTE 10 PRO / REDMI NOTE 10 PRO 4G / REDMI NOTE 10S / REDMI NOTE 10S / REDMI NOTE 11 4G / REDMI NOTE 11 PRO 4G / REDMI NOTE 11 PRO 5G / REDMI NOTE 11 PRO+ 5G / REDMI NOTE 11S 4G / REDMI NOTE 11S 5G / REDMI NOTE 12 4G / REDMI NOTE 12 5G / REDMI NOTE 12 PRO / REDMI NOTE 12 PRO+ / REDMI NOTE 13 4G / REDMI NOTE 13 5G / REDMI NOTE 13 PRO 5G / REDMI NOTE 13 PRO+ / REDMI NOTE 7 / REDMI NOTE 8 / REDMI NOTE 8 (2021) / REDMI NOTE 8 PRO / REDMI NOTE 8T / REDMI NOTE 9 / REDMI NOTE 9 PRO / REDMI NOTE 9S / REDMI NOTE 9T / Xiaomi 11 Lite 5G NE / XIAOMI 13 / XIAOMI 13 PRO / XIAOMI 13T / XIAOMI 13T PRO / XIAOMI 14 / XIAOMI 14 PRO