

Galaxy SmartTag 2 Bluetooth® object trackers Black White Samsung



Descriptif produit



Hook it. Locate it. So you don't get lost again.

The little hero that makes everyday life easier

Monday morning, 8.30am, you're just in time to catch your train, but you can't find your keys. Luckily, your Galaxy SmartTag2 is there. Instead of searching everywhere for your keys during the 15 precious minutes that will make you miss your train, you calmly take your Galaxy smartphone and locate them in the blink of an eye thanks to SmartThings. You've saved 12 minutes, and the price of your train ticket!

It watches over you everywhere, in all weathers, and for a long time to come. Thanks to its small keyring size, the Galaxy SmartTag2 can be attached to all your everyday objects. And with a battery life of 500 days (and up to 700 days in energy-saving mode), it's easy to forget. And that's just as well! All-terrain and hard-wearing, you can forget about it without fear. Thanks to its IP67 certification, it'll find your things anywhere, even when your little nephew has put your keys in the water or your dog has spent the day outside rolling around in the mud. This little hero even gets involved when it comes to helping around the house, thanks to its IoT functions that can be configured in the SmartThings application.

Say goodbye to hours of searching and stress, let yourself be guided. Save yourself the famous "Can you remember the last time you saw it?", the SmartThings interface will point it out for you. Save time, energy and peace of mind. Once you've registered your SmartTag2 in SmartThings, finding your items is simple and intuitive.

Right there. A little to the left.

Follow the nearby search instructions, which will tell you how far away the object is and in which direction to look. If you still can't see your object, ring the Galaxy SmartTag2 remotely via your smartphone. There's no excuse for not finding your keys!

Really lost? Let us help you

When Lost Mode is activated, your Galaxy SmartTag2 can be read by another Galaxy smartphone using NFC (Near Field Communication) technology. Your SmartTag2 will then display your contact details and saved message on the smartphone. If someone finds your object with the SmartTag2 on it, all they have to do is flash it via their smartphone, and they can contact you to return it.

A hero that adapts to all your uses, but always in style.

Need extra protection and an integrated carabiner to attach the SmartTag2 to your favourite objects? Make it a truly colourful accessory that complements your style.

Galaxy smartphone & Tablet running Android 9.0 or later + 3GB RAM minimum / Requires SmartThings application

Color : Black White

Ref : EI-T5600KW

EAN : 8806095039763

Pack contents : 4 Galaxy SmartTag2 + 1 battery included + 1 battery removal tool + 1 user manual

Informations complémentaires

Connectivity

Bluetooth: BLE v5.3

UWB : O

Distance : Up to 120 metres

Battery

Product type : Replaceable CR2032 battery

Battery life: Up to 500 days in standard mode and 700 days in energy-saving mode (configurable in the SmartThings app)

Physical specifications

Product dimensions: 28.8 x 52.44 x 8.0 mm

Weight: 13.75 g

Compatibility

Compatible models: Galaxy smartphone & Tablet running Android 9.0 or later + 3GB RAM minimum /

Requires SmartThings application

General specifications

Resistance: IP67

Speakers: Ringer

Buttons: 1

Compatible mobiles

SAMSUNG

SMARTTAG 2 / G WATCH / G WATCH FE / G WATCH ULTRA / G WATCH3 / G WATCH4 / G WATCH4 CLASSIC / G WATCH5 / G WATCH5 PRO / G WATCH6 / G WATCH6 CLASSIC / G WATCHACT / G WATCHACT2 / GALAXY A02s A025/026 / GALAXY A03 A035 / GALAXY A03S / GALAXY A04S / GALAXY A05s 057 / GALAXY A10 A105 / GALAXY A12 A125 / GALAXY A13 4G A135 / GALAXY A13 5G A136 / GALAXY A14 4G A145 / GALAXY A14 5G A146 / GALAXY A15 5G 156 / GALAXY A20 / GALAXY A20e A202 / GALAXY A21S A217 / GALAXY A22 4G / GALAXY A22 5G / GALAXY A23 5G / GALAXY A25 256 / GALAXY A3 A300 / GALAXY A3 A310 2016 / GALAXY A3 A320 2017 / GALAXY A31 A315 / GALAXY A32 4G / GALAXY A32 5G / GALAXY A33 5G A336 / GALAXY A34 5G A346 / GALAXY A35 5G 356 / GALAXY A40 A405 / GALAXY A41 A415 / GALAXY A42 5G / GALAXY A5 A500 / GALAXY A5 A510 2016 / GALAXY A5 A520 2017 / GALAXY A50 A505 / GALAXY A51 5G A516 / GALAXY A51 A515 / GALAXY A52 4G / GALAXY A52 5G / GALAXY A52s 5G / GALAXY A53 5G A536 / GALAXY A54 5G A546 / GALAXY A55 5G 556 / GALAXY A6 A600 2018 / GALAXY A6+ A605 2018 / GALAXY A7 A700 / GALAXY A7 A750 2018 / GALAXY A70 A705 / GALAXY A71 A715 / GALAXY A72 4G / GALAXY A8 A530 2018 / GALAXY A80 A805 / GALAXY A9 A920 2018 / GALAXY ACE 3 S7270 / GALAXY ACE 4 4G G357 / GALAXY ACE S5830 / GALAXY ALPHA G850 / GALAXY BUDS LIVE / GALAXY CAMERA GC100 / GALAXY CORE 4G G386 / GALAXY CORE I8260 / GALAXY CORE PLUS G3500 / GALAXY CORE PRIME G360 / GALAXY EXPRESS I8730 / GALAXY FOLD / GALAXY GRAND 2 G7100 / GALAXY GRAND PRIME G530 / GALAXY J1 J100 / GALAXY J1 J120 2016 / GALAXY J2 PRO J250 2018 / GALAXY J3 J320 2016 / GALAXY J4+ J415 / GALAXY J5 J500 / GALAXY J5 J510 2016 / GALAXY J6 J600 / GALAXY J6+ J610 / GALAXY J7 J710 2016 / GALAXY M52 5G M526 / GALAXY MEGA 5.8 I9150 / GALAXY MEGA I9200 / GALAXY NEXUS I9250 / GALAXY NOTE 10 + N975 / GALAXY NOTE 10 LITE / GALAXY NOTE 10 N970 / GALAXY NOTE 2 N7100 / GALAXY NOTE 20 5G / GALAXY NOTE 20 ULTRA / GALAXY NOTE 3 LITE N7505 / GALAXY NOTE 3 N9000 / GALAXY NOTE 4 N910 / GALAXY NOTE 9 N960 / GALAXY S 10 + G975 / GALAXY S 10 5G G977 / GALAXY S 10 e G970 / GALAXY S 10 G973 / GALAXY S 10 LITE G770 / GALAXY S 20 + G985 / GALAXY S 20 FE G780 / GALAXY S 20 G980 / GALAXY S 20 ULTRA G988 / GALAXY S 21 5G 991 / GALAXY S 21 FE 990 / GALAXY S 21 ULTRA 5G 998 / GALAXY S 21+ 5G 996 / GALAXY S 22 5G 901 / GALAXY S 22 ULTRA 5G 908 / GALAXY S 22+ 5G 906 / GALAXY S 23 5G 911 / GALAXY S 23 FE 711 / GALAXY S 23 ULTRA 5G 918 / GALAXY S 23+ 5G 916 / GALAXY S 24 921 / GALAXY S 24 ULTRA 928 / GALAXY S 24+ 926 / GALAXY S 3 4G I9305 / GALAXY S 3 I9300 / GALAXY S 3 MINI I8190 / GALAXY S 4 I9500 / GALAXY S 4 MINI I9190 / GALAXY S 4 ZOOM / GALAXY S 5 G900 / GALAXY S 5 MINI G800 / GALAXY S 6 EDGE G925 / GALAXY S 6 EDGE PLUS G928 / GALAXY S 6 G920 / GALAXY S 7 EDGE G935 / GALAXY S 9 + G965 / GALAXY S 9 G960 / GALAXY TAB 10.1 P7100 / GALAXY TAB 2 10.1 P5110 / GALAXY TAB 4 10.1 T530 / GALAXY TAB 4 7.0 T230 / GALAXY TAB A 10.1 (2019) / GALAXY TAB A 10.1 T580 (2016) / GALAXY TAB A 10.5 2018 / GALAXY TAB A 7.0 T280 (2016) / GALAXY TAB A 8 T295 (2019) / GALAXY TAB A 8.0 (2020) / GALAXY TAB A7 10.4 (2020) T505 / GALAXY TAB A7 Lite 8.7 T220 / GALAXY TAB A8 10.5 X200-205 / GALAXY TAB A8 8 (2017) / GALAXY TAB A9 / GALAXY TAB A9+ / GALAXY TAB ACTIVE 2 / GALAXY TAB ACTIVE 4 PRO 5G / GALAXY TAB ACTIVE 5 / GALAXY TAB ACTIVE 5 EE / GALAXY TAB ACTIVE PRO / GALAXY TAB ACTIVE2 / GALAXY TAB ACTIVE3 / GALAXY TAB S 10.5 T800 / GALAXY TAB S5E / GALAXY TAB S6 LITE 10.4 / GALAXY TAB S7 10 / GALAXY TAB S7 FE 12.4 T730 / GALAXY TAB S7+ 12.4 T970 / GALAXY TAB S9 / GALAXY TAB S9 FE / GALAXY TAB S9 ULTRA / GALAXY TAB S9+ / GALAXY TREND 2 LITE G318 / GALAXY TREND LITE S7390 / GALAXY XCOVER 3 G388 / GALAXY XCOVER 4S / GALAXY XCOVER 5 G525F / GALAXY XCOVER 6 PRO / GALAXY XCOVER 7 / GALAXY XCOVER PRO / GALAXY Z FLIP 3 711 / GALAXY Z FLIP 6 741 / GALAXY Z FLIP 700 / GALAXY Z FOLD 2 5G 916 / GALAXY Z FOLD 3 926 / GALAXY Z FOLD 4 936 / GALAXY Z FOLD 5 946 / GALAXY Z FOLD 6 956