



PNY

Carte MicroSD Performance Plus 128GB Class 10 50 MB/S PNY

Les cartes microSD Performance Plus vous permettent de tirer le meilleur de vos smartphones et tablettes pour télécharger et lire de la musique, des jeux, des vidéos, et bien plus.

GENCODE :
0751492625690



REF. :

PNYMICROSDPP128GO

Caractéristiques

Ajoutez de l'espace de stockage à votre smartphone et profitez d'encore plus de contenus mobiles comme des applications, des eBooks, des vidéos, de la musique et des films.

Classées dans la catégorie 10, les cartes microSD Performance Plus sont idéales pour transférer et partager rapidement vos contenus pendant vos déplacements. Les utilisateurs professionnels pourront stocker davantage d'e-mails, de documents et de présentation pour y accéder facilement lorsqu'ils ne sont pas au bureau.

Disponible avec une capacité de stockage allant de 16 GB à 128 GB, la carte microSD Performance Plus stockera tous vos contenus.

Certifiée Classe 10, elle garantit une vitesse d'écriture minimum de 10MB/s.

Compatible avec la plupart des appareils dotés d'un port microSD, dont des smartphones, des tablettes, des caméras de vidéosurveillance, et bien plus.

Résistante aux perturbations magnétiques, aux chocs, aux écarts de température et à l'eau

Dimensions	Universel
Contenu du pack	1 Carte MicroSD Performance Plus

MOBILES COMPATIBLES

ALCATEL

1 (5033) / 1B 2020 / 1S (2020) / 1S (2021) / 1S (5024) / 1X (5059) / 1X 2019 (5008) / 3 (5052) / 3C (5026) / 3L (5034) / 3L 2020 / 3V (5099) / 3X (5058) / 3X 2019 (5048) / 5 (5086) / 5V (5060) / A3 / A3 XL / A5 LED / IDOL 3 (4.7) / IDOL 4 / ONE TOUCH IDOL 2S / POP 3 5.0 / POP 4 / U5

APPLE

IPAD PRO 10.5

BLACKBERRY

CURVE 9320 / KEY2 / Q10 / Q5

CROSSCALL

ACTION X3 / CORE M4 / CORE M5 / CORE X3 / CORE X4 / TREKKER X3 / TREKKER M 1 / TREKKER X4

DORO

6050 / 6530 / 7070 / 7080 / 8040 / 8042 / 8080 / PHONEEASY 612

ECHO

BUZZ / DUNE / FEELING / FLOW / FUSION / HALO / HORIZON / HORIZON LITE / HORIZON LITE PLUS / HORIZON M / JAVA / LOLLY / LOOK / NOTE / PUSH / SMART4G / STAR / STELLAR / SURF / VOLT / WIZ

HONOR

9A / 9X LITE / HONOR 10 / HONOR 10 LITE / HONOR 10X LITE / HONOR 20 LITE / HONOR 5C / HONOR 5X / HONOR 6A / HONOR 6C / HONOR 6C PRO / HONOR 6X / HONOR 7A / HONOR 7C / HONOR 7S / HONOR 7X / HONOR 8 / HONOR 8A / HONOR 8S / HONOR 8X / HONOR 9 / HONOR 9 LITE / HONOR 9X / HONOR PLAY

HTC

10 / DESIRE 530 / DESIRE 650 / DESIRE 825 / ONE A9 / ONE M8 / ONE M9 / U PLAY / U11

HUAWEI

ASCEND P7 / MATE 10 LITE / MATE 10 PRO / MATE 20 LITE / MATE S / P SMART / P SMART 2019 / P SMART 2020 / P SMART 2021 / P SMART PRO 2019 / P SMART Z / P10 / P10 Lite / P10 PLUS / P20 / P20 LITE / P20 LITE 2019 / P20 PRO / P30 LITE / P40 LITE E / P8 / P8 LITE 2016 / P8 LITE 2017 / P9 / P9 LITE / Y3 / Y5 2018 / Y5 2019 / Y5 II / Y5P / Y6 2017 / Y6 2019 / Y6 PRO 2017 / Y6P / Y6S (2019) / Y7 2018 / Y7 2019

LOGICOM

E350 / E500

MOTOROLA

MOTO E4 PLUS / MOTO G30 / MOTO G50 5G

NOKIA

1 2018/2/3/3.1/3310 2017/5/5.1/5.1 PLUS/6/6 2018/6.1/7 PLUS/7.1/XL

OPPO

A12/A15/A16/A16 S/A3/A5 (2020)/A53S/A54 4G/A72/A73 4G/A73 5G/A74/A74 5G/A9 (2020)/A94 5G/AX7/FIND X/R15 PRO/RENO 10X ZOOM/RENO 2/RENO 2F/RENO 2Z/RENO 4/RENO 5 LITE/RENO 6/RENO 6 PRO/RX17 NEO

ORANGE

NEVA JET/NEVA PLAY/NEVA ZEN

REALME

7i/8 5G/8 Pro 4G/8i/C11/C11 2021/C21/C21Y/C25

SAMSUNG

GALAXY A02s A025/026/GALAXY A03S/GALAXY A10 A105/GALAXY A12 A125/GALAXY A20/GALAXY A20e A202/GALAXY A21S A217/GALAXY A22 4G/GALAXY A22 5G/GALAXY A3 A300/GALAXY A3 A310 2016/GALAXY A3 A320 2017/GALAXY A31 A315/GALAXY A32 4G/GALAXY A32 5G/GALAXY A40 A405/GALAXY A41 A415/GALAXY A42 5G/GALAXY A5 A500/GALAXY A5 A510 2016/GALAXY A5 A520 2017/GALAXY A50 A505/GALAXY A51 5G A516/GALAXY A51 A515/GALAXY A52 4G/GALAXY A52s 5G/GALAXY A6 A600 2018/GALAXY A6+ A605 2018/GALAXY A7 A700/GALAXY A7 A750 2018/GALAXY A70 A705/GALAXY A71 A715/GALAXY A72 4G/GALAXY A8 A530 2018/GALAXY A9 A920 2018/GALAXY ACE 3 S7270/GALAXY ACE 4 4G G357/GALAXY ACE S5830/GALAXY CAMERA GC100/GALAXY CORE 4G G386/GALAXY CORE I8260/GALAXY CORE PLUS G3500/GALAXY CORE PRIME G360/GALAXY EXPRESS I8730/GALAXY GRAND 2 G7100/GALAXY GRAND PRIME G530/GALAXY J1 J100/GALAXY J1 J120 2016/GALAXY J2 PRO J250 2018/GALAXY J3 J320 2016/GALAXY J3 J330 2017/GALAXY J4+ J415/GALAXY J5 J500/GALAXY J5 J510 2016/GALAXY J5 J530 2017/GALAXY J6 J600/GALAXY J6+ J610/GALAXY J7 J710 2016/GALAXY J7 J730 2017/GALAXY MEGA 5.8 I9150/GALAXY MEGA I9200/GALAXY NOTE 10 + N975/GALAXY NOTE 10 LITE/GALAXY NOTE 2 N7100/GALAXY NOTE 3 LITE N7505/GALAXY NOTE 3 N9000/GALAXY NOTE 4 N910/GALAXY NOTE 8 N950/GALAXY NOTE 9 N960/GALAXY S 10 + G975/GALAXY S 10 e G970/GALAXY S 10 G973/GALAXY S 10 LITE G770/GALAXY S 20 + G985/GALAXY S 20 FE G780/GALAXY S 20 G980/GALAXY S 20 ULTRA G988/GALAXY S 21 FE 990/GALAXY S 3 4G I9305/GALAXY S 3 I9300/GALAXY S 3 MINI I8190/GALAXY S 4 I9500/GALAXY S 4 MINI I9190/GALAXY S 4 ZOOM/GALAXY S 5 G900/GALAXY S 5 MINI G800/GALAXY S 7 EDGE G935/GALAXY S 7 G930/GALAXY S 8 + G955/GALAXY S 8 G950/GALAXY S 9 + G965/GALAXY S 9 G960/GALAXY TAB 10.1 P7100/GALAXY TAB 2 10.1 P5110/GALAXY TAB 4 10.1 T530/GALAXY TAB 4 7.0 T230/GALAXY TAB A 10.1 (2019)/GALAXY TAB A 10.1 T580 (2016)/GALAXY TAB A 10.5 2018/GALAXY TAB A 7.0 T280 (2016)/GALAXY TAB A 8.0 (2020)/GALAXY TAB A7 10.4 (2020) T505/GALAXY TAB A7 Lite 8.7 T220/GALAXY TAB A8 8 (2017)/GALAXY TAB ACTIVE 2/GALAXY TAB ACTIVE PRO/GALAXY TAB ACTIVE2/GALAXY TAB ACTIVE3/GALAXY TAB S 10.5 T800/GALAXY TAB S5E/GALAXY TAB S6 LITE 10.4/GALAXY TAB S7 10/GALAXY TREND 2 LITE G318/GALAXY TREND LITE S7390/GALAXY XCOVER 3 G388/GALAXY XCOVER 4/GALAXY XCOVER 4S/GALAXY XCOVER 5 G525F/GALAXY XCOVER PRO

SFR

STARSHINE 5/STARTRAIL 6/STARTRAIL 8

SONY

LG K51S/XPERIA 1/XPERIA 10/XPERIA 10 II/XPERIA 10 PLUS/XPERIA 5/XPERIA 5 II/XPERIA E1/XPERIA E5/XPERIA L1/XPERIA L3/XPERIA M4 AQUA/XPERIA T3/XPERIA X/XPERIA XA/XPERIA XA1 ULTRA/XPERIA XA2/XPERIA XA2 PLUS/XPERIA XA2 ULTRA/XPERIA XZ/XPERIA XZ PREMIUM/XPERIA XZ1/XPERIA XZ1 COMPACT/XPERIA XZ2/XPERIA XZ3/XPERIA Z/XPERIA Z2/XPERIA Z3/XPERIA Z3 COMPACT/XPERIA Z5/XPERIA Z5 COMPACT

VIVO

V21/V21 5G/Y11/Y11s/Y20/Y20s/Y21/Y33s/Y52 5G/Y70/Y72 5G

WIKO

BIRDY/CINK FIVE/CINK PEAX/CINK PEAX 2/DARKMOON/DARKKNIGHT/FEVER/FREDDY/HARRY/HARRY 2/JERRY/JERRY 2/JERRY 3/LENNY/LENNY 2/LENNY 3/LENNY 4/LENNY 5/OZZY/POWER U10/POWER U30/PULP 4G/PULP FAB/RAINBOW 4G/RAINBOW JAM 4G/RAINBOW LITE 4G/ROBBY/STAIRWAY/SUNNY/SUNNY 2/SUNNY 2 PLUS/SUNNY 3/SUNSET 2/TOMMY/TOMMY 2/TOMMY 2 PLUS/TOMMY 3/U FEEL LITE/U PULSE/U PULSE LITE/VIEW/VIEW 3/VIEW 3 LITE/VIEW 4/VIEW 4 LITE/VIEW 5/VIEW 5 PLUS/VIEW GO/VIEW LITE/VIEW MAX/VIEW PRIME/VIEW XL/VIEW2/WIM/WIM LITE/Y50/Y51/Y60/Y61/Y62/Y62 Plus/Y80/Y81

XIAOMI

MI 10 LITE 5G/MI 10T LITE 5G/MI 8 LITE/MI 9 LITE/MI A1/MI A2/MI A3/MI MIX 2/MI MIX 2S/MI NOTE 9/POCOPHONE F1/REDMI 10/REDMI 5/REDMI 6/REDMI 6A/REDMI 7/REDMI 8/REDMI 8A/REDMI 9/REDMI 9A/REDMI 9T/REDMI GO/REDMI NOTE 10/REDMI NOTE 10 5G/REDMI NOTE 10S/REDMI NOTE 10S/REDMI NOTE 5/REDMI NOTE 7/REDMI NOTE 8/REDMI NOTE 8 (2021)/REDMI NOTE 8 PRO/REDMI NOTE 8T/REDMI NOTE 9/REDMI NOTE 9 PRO/REDMI NOTE 9S/REDMI NOTE 9T/REDMI S2